



bridge
the gap

Quick Start Guide

UP Squared 6000 Edge Computing Kit

Up to 1.7x improvement in single-thread performance and up to 2x performance for 3D graphics compared with previous generation Intel processors.

I/O interfaces include 1x USB 3.2 Type-C (OTG support), 2x USB 3.2 Type-A, 1x Micro USB (debug port), 2x COM ports, 2x SATA 3.0, 1x full sized Mini-Card slot (via USB 2.0), 1x M.2 2230 E key, 1x M.2 2280 M key, 1x M.2 3052 B key with micro-SIM card slot, 1x HDMI 2.0b, 1x DP 1.2, Audio jack line I/O, 1x 40-pin HAT PSE header, 1x 40-pin HAT header, 4x GbE

WHAT 'S IN YOUR KIT ?



1x UP Squared 6000 main board
1x Carrier board



1x UP Squared 6000 system

Ubuntu 20.04

Intel® Edge Insights for Vision software package



1x 12V6A (72W) Power Supply

1x US power cord

1x EU power cord

You will need to have the following:

- A monitor with HDMI or DP, and respective cables.
- USB keyboard and mouse.
- Ethernet cable or WiFi module (optional, to be installed manually).
- UP AI Core XM 2280 M.2 module (optional for UPN-EDGE-EHLX-4RE-A10-0864-FDK, to be installed manually).

* UPN-EDGE-EHLX4RE-A10-FDKAI comes with XM 2280 installed (2x Intel® Movidius™ Myriad™ X)

1 GET READY



- The **UP Squared 6000 Edge Computing Kit** comes with **passive cooling, RTC battery, onboard RAM and eMMC.**
- The system comes with Ubuntu 20.04 Desktop including the **Intel® Edge Insights for Vision** software package.
- Please follow these steps **carefully** before connecting cables and powering ON the system.

2 CONNECT HARDWARE



- 1 Connect Ethernet cable
- 2 Connect Monitor
- 3 Connect your USB device
- 4 Connect Power

3 SETUP DETAILS

1. Connect the monitor with the system powered down.
2. Power up the system. The system will turn on automatically and boot into the OS.
3. Log in to the Ubuntu 20.04 OS with the following credentials:
username: **devkit**
password: **devkit**
- If proxy settings are required, you can set them from:
System Settings > Network > Network Proxy
4. Get Started with Intel® Edge Insights for Vision
<https://www.intel.com/content/www/us/en/developer/articles/training/devkit-gsg21.html>

Caution: This is a high performance system and may get hot during operation.

Expand your UP Squared 6000 Edge Computing Kit to fit your exact needs



 **M.2 2230 WiFi Kit with UP Squared 6000**
Intel® Wireless-AC 9260
(802.11ac, Bluetooth® 5.0)



 **UP AI Core XM 2280 with UP Squared 6000**
AI hardware accelerator with 2x Intel® Movidius™
Myriad™ X



**QUESTIONS?
REACH US HERE**



UP Community
<https://www.up-community.org>

Product Specifications

System	UP Squared 6000 Edge Computing Kit
SoC	Intel Atom® x6425RE 1.90GHz
# of Cores	Quad Core
Graphics	Intel® UHD Graphics
VPU	Optional (via M.2 2280)
System memory	8GB via 2 Channel LPDDR4
Storage capacity	64GB Optional (via 2x SATA / 1x M.2 2280)
Power Requirement	DC-IN (12V) lockable power connector
Power Supply Type	AT/ATX (default AT mode)
Power Consumption(Typical)	62W

China RoHS Requirements

Component Name	Hazardous or Toxic Materials or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium (Cr(VI))	Hexavalent biphenyls (PBbs)	Polybrominated diphenyl ethers (PBDEs)
PCB and Components	0	0	0	0	0	0
Wires & Connectors for Ext. Connections	0	0	0	0	0	0
CPU & RAM	0	0	0	0	0	0

This form is prepared in compliance with the provisions of SJ/T 11364.
O: The level of toxic or hazardous materials present in this component and its parts is below the limit specified by GB/T 26572.
X: The level of toxic or hazardous materials present in the component exceed the limits specified by GB/T 26572, but is still in compliance with EU Directive 2011/65/EU (RoHS 2).

Notes:
1. The Environment Friendly Use Period indicated by labeling on this product is applicable only to use under normal conditions.
2. Individual components including the CPU, RAM/memory, HDD, optical, and PSU are optional.
3. LCD Module and Touch Control Module only applies to certain products which feature these components.

Safety Precaution

Please read the following safety instructions carefully. It is advised that you keep this quick start guide for future references.

1. Take note of all cautions and warnings on the device.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people do not step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. Do not make any connections while the device is powered on.
A sudden rush of power may damage sensitive electronic components.
6. If you plan to not use the device for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any power supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent it from falling.
12. Do not cover the openings on the chassis. This is to ensure optimal heat dissipation.
13. Keep an eye for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running.
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself when installing internal components in any static-shielded containers.
17. If any of the following situations arise, please contact our service personnel:
 - I. Damaged power cord or power supply
 - II. Liquid intrusion through the device
 - III. Exposure to moisture
 - IV. Device is not working as expected or in a manner as described in this quick start guide
 - V. The device is dropped or damaged
 - VI. Any obvious signs of signs of damage on the device
18. Do not operate the device in an uncontrolled environment temperatures beyond 60 °C.
19. Store the device between -40°C to 80°C to prevent damage.

FCC Statement

This device complies with Part FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution: There is a danger of explosion if the battery is incorrectly replaced, replaced only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention: Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

Regulatory

