



QUICK START GUIDE SIGFOX REPEATER

Installation kit - Presentation



- | | | |
|----|-----------------------------------|----|
| 1. | Hard case | x1 |
| 2. | Repeater ARF8168AA | x2 |
| 3. | Reference transmitter ARF8260AA | x1 |
| 4. | Magnet | x1 |
| 5. | Micro USB Cable | x1 |
| 6. | OTG USB Cable | x1 |
| 7. | OTG Micro USB Cable | x1 |
| 8. | Repeater fixation set | x2 |
| 9. | Repeater transparent bottom cover | x2 |

How to get started with your repeater?

1. Register your Repeater on sigfox backend on your account (as any other device).

2. Download the Sigfox Repeater Application (Google play or Windows) and it will take you through all the steps.


Alternative: start your repeater (position a magnet on white circle). The repeater will automatically switch on the « auto record » mode (see attached page).

3. Check the network coverage thanks to a Field Test device from adeunis® or following the steps in the section "environment" of the application. Then pick the best position for the repeater.

4. You are done ! Let's make sure everything works well. Go back on your Sigfox backend account. You should see all your repeater information as well as the repeated messages (with a « R » right next to the frame).

5. For more information: see the dedicated repeater page and download the complete User Guide:

<https://www.adeunis.com/en/produit/repeater-sigfox/>



flash it!

adeunis ®

283 rue Louis Néel - Parc Technologique Pré Roux
38920 CROLLES - France
www.adeunis.com

Pick your favourite options to set up the whitelist of your repeater!

Auto Record



Start your device. In this mode, the repeater will automatically select each day the 15 first seen devices and repeat their messages. As such, the list of repeated devices may change daily. If the repeater happens to be nearby many devices, we suggest to use option 2 or 3 to select the right devices.



Configure via USB

Use the Repeater application and enter your Sigfox IDs in the Whitelist section or configure the corresponding registers via AT commands. *Please have a look at our tips & warnings section to avoid easy mistakes.*



Configure via the network

Start your device and switch to INSTALLATION mode (with the application or through a downlink). Send IDs remotely thanks to one or several DL frames.

TIPS & WARNINGS

Make sure to use the OTG cable properly




The OTG cables must never be plugged on the repeater. It must be plugged on the smartphone or the tablet.

Make sure you can indeed use option 2



Sometimes, the repeater is not properly recognized by your smartphone or tablet. As such, we advise to use the application called « USB OTG Checker » and check that your device is actually compatible (information usually available in the Settings).

Make sure the seal is not twisted



When you close the casing and in order to conserve the IP67 protection, be sure that the seal is not twisted or that the soleplate is correctly clipped.

210621A



Headquarters & Warehouse

Elektrostraat 17
NL-7483 PG Haaksbergen
The Netherlands

T: +31 (0)53 573 33 33
E: info@texim-europe.com
Homepage: www.texim-europe.com



The Netherlands

Elektrostraat 17
NL-7483 PG Haaksbergen

T: +31 (0)53 573 33 33
E: nl@texim-europe.com



Belgium

Zuiderlaan 14, box 10
B-1731 Zellik

T: +32 (0)2 462 01 00
E: belgium@texim-europe.com



UK & Ireland

St Mary's House, Church Lane
Carlton Le Moorland
Lincoln LN5 9HS

T: +44 (0)1522 789 555
E: uk@texim-europe.com



Germany - North

Bahnhofstrasse 92
D-25451 Quickborn

T: +49 (0)4106 627 07-0
E: germany@texim-europe.com



Germany - South

Martin-Kollar-Strasse 9
D-81829 München

T: +49 (0)89 436 086-0
E: muenchen@texim-europe.com



Austria

Warwitzstrasse 9
A-5020 Salzburg

T: +43 (0)662 216 026
E: austria@texim-europe.com



Nordic

Søndre Jagtvej 12
DK-2970 Hørsholm

T: +45 88 20 26 30
E: nordic@texim-europe.com



Italy

Via Matteotti 43
IT-20864 Agrate Brianza (MB)

T: +39 (0)39 9713293
E: italy@texim-europe.com