M-G32EV041



Data Sheet USB Evaluation Cable Interface Board for EPSON IMU/ Accelerometer

This IMU/ Accelerometer USB evaluation Cable Interface board is used to control EPSON / IMU(M-G320/M-G354/M-G364/M-G365/M-G370/M-G220) and Accelerometer /M-A352 from PC by way of USB. The preliminary evaluation of our IMU/ Accelerometer is facilitated by using this IMU/ Accelerometer USB evaluation Cable Interface board.

BLOCK DIAGRAM




Fig1. Block Diagram

■ RECOMMENDED OPERATING CONDITION

Microsoft Windows7/ 8.1/ 10 (64bit) are supported when the USB interface of the USB Evaluation Cable is connected to the PC. Other hardware connection or software environments are not tested by Epson.

Table1. Recommended Operating Condition		
Support OS	Windows 7/ 8.1/ 10 (64bit)	
USB Specification	1.1 / 2.0	
Operation Temperature	-20~+70°C	

Distributed by:	
www.texim-europe.com	

M-G32EV041

CN2 (Opposing surface) USB Type-C CN2 (Opposing surface) CN2 (Opposing surface) CN4 : M-G32EV051 Connected connector CN4 : M-G32EV051 Connected connector CN1 (Opposing surface) : Product connection connector

Fig2. Board Outline Dimensions (millimeters)

PIN FUNCTION

Pin No.	Mnemonic	Type ^{*1}	Description
1	SCLK	I	SPI Serial Clock
2	SDO	0	SPI Data Output
5	SDI	1	SPI Data Input
6	/CS	I	SPI Chip Select
7	SOUT	0	UART Data Output
9	SIN	1	UART Data Input
13	DRDY (GPIO1)	I/O	Data Ready (General Purpose I/O1)
14	GPIO2 (EXT)	I/O	General Purpose I/O2 (External Trigger Input or External Counter Reset Input)
16	/RST	1	Reset
10,11,12	VCC	S	Power Supply 3.3V
3,4,8,15	GND	S	Ground
17,18,19,20	NC		


Table2. CN1 Pin Function Description

*) Please refer to the product-specific documentation about details of each terminal.

Table3. CN4 Pin Function Description

Pin No.	Mnemonic	Type ^{*1}	Description
1	NC		
2	DRDY	I/O	Data Ready
	(GPIO1)	1/0	(General Purpose I/O1)
3	SIN	I	UART Data Input
4	SOUT	0	UART Data Output
5	GND	S	Ground
6	VCC	S	Power Supply 3.3V
7	GPIO2 (EXT)	I/O	General Purpose I/O2 (External Trigger Input or
8	NC		External Counter Reset Input)
9	/RST	I	Reset

M-G32EV041



(1) IMU-G-Series – USB evaluation board connection
(2) Accelerometer – USB evaluation board connection
Fig3. IMU Installation

BUNDLED PARTS

Table4. Bundled Parts List

Product Number	Product Name	Specifications	Quantity
1	Sems Screw for IMU	M2 L=8mm	2
2	Nut	Hex Nut M2	2
3	Sems Screw for Accelerometer	M2 L=25mm	3
4	Spacer	M2 L=5mm	4
5	Screw	M2 L=4	4

FTDI Driver

If the driver software (USB Serial Converter, USB Serial Port (COMx)) is requested when the USB Evaluation Cable is connected, install the driver using either of the following two methods.

• Update the driver via Windows Device Manager. (Automatic Update over the Internet is recommended.)

http://global.epson.com/products_and_drivers/sensing_system/technical_info/evaluation_tools/

• Access the FTDI website (http://www.ftdichip.com/Drivers/VCP.htm) and download the appropriate driver for the OS.

■ IMU LOGGER SOFTWARE

The IMU logger software is provided for use with the USB Evaluation Cable and USB Evaluation Cable Interface Boards to allow easy evaluation of the Epson IMUs. For information about the IMU logger software, contact our representatives.

■ IMPORTANT NOTES OF USE

Software & Manuals Download Website:

- Please read the caution sheet that is bundled before use.
- This "USB Evaluation Cable Interface Board" communicates with IMU/ Accelerometer through the USB Cable(Type-C). Please refer to the list in the 'Supported Devices' section to determine the supported IMU/ Accelerometer model.
- Please ensure that the IMU/ Accelerometer & USB Evaluation Cable Interface Board is properly connected before inserting or removing the USB cable.
- Do not insert or remove the USB cable immediately after connecting.
- The IMU/ Accelerometer & USB Evaluation Cable Interface Board can be easily moved by the USB cable resulting in possible damage by the impact. Please take precaution to prevent impact by restraining the IMU/ Accelerometer & USB Evaluation Cable Interface Board.
- When removing the IMU/ Accelerometer from USB Evaluation Cable Interface Board, do not remove the IMU/ Accelerometer casing assembly bonded-screws. Removing the IMU/ Accelerometer casing assembly bonded-screws will void the product warranty.

4



For Contact

SEIKO EPSON CORPORATION

MSM Business PROJECT

DEVICE Sales and Marketing Department

TEL: +81-266-61-0614, FAX: +81-266-61-2051

PRODUCT NUMBER AND ORDER INFORMATION

Please order using the following number.

Order Number	Product Number	Comment	
E92E609041 M-G32EV041		USB Evaluation Cable Interface Board	

Evaluation Board/Kit and Development Tool Important Notice

- 1. This evaluation board/kit or development tool is designed for engineering evaluation, demonstration, or development purposes only. Do not use it for any other purposes. The conformance test for this product in accordance with European EMC regulations and United States FCC regulations has not been conducted.
- 2. This evaluation board/kit or development tool is intended for use by electronics engineers and is not a consumer product. Malfunction by the electrical noise may result from usage depending on your environment. The user should ensure it is used in a safe and proper manner.
- 3. Seiko Epson does not assume any responsibility or liability of any kind from damage and/or fire caused by the use of this evaluation board/kit or development tool. The user should cease using this evaluation board/kit or development tool if any abnormal issue occurs even during proper and safe usage.
- 4. When disposing of this evaluation board/kit or development tool, discard in accordance with domestic law concerning disposal.
- 5. The parts used for this evaluation board/kit or development tool may be changed without notice.
- 6. Do not allow heaters, human body or metal parts to contact the non-insulated parts of this evaluation board/kit or development tool.
- 7. Do not allow the human body or metal parts to contact any openings of this evaluation board/kit or development tool.
- 8. Do not allow excessive stress on mounted components, board wiring, and electric wire of this evaluation board/kit or development tool.
- 9. When exporting the products or technology described in this material, the user should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. Do not use, resell, export and/or otherwise disclose of these products (and any technical information, if any) for the development and/or manufacture of weapons of mass destruction or other military purposes.

NOTICE

No part of this material may be reproduced or duplicated in any form or by any means without the written permission of Seiko Epson. Seiko Epson reserves the right to make changes to this material without notice. Seiko Epson does not assume any liability of any kind arising out of any inaccuracies contained in this material and, further, there is no representation that this material is applicable to products requiring high level reliability, such as, medical products. Moreover, no license to any intellectual property rights is granted by implication or otherwise, and there is no representation or warranty that anything made in accordance with this material will be free from any patent or copyright infringement of a third party. Keep this manual at hand to answer any questions you have about this product during use. All brands or product names mentioned herein are trademarks and/or registered trademarks of their respective companies.

©Seiko Epson Corporation 2018, All rights reserved.

SEIKO EPSON CORPORATION

MSM BUSINESS PROJECT

281, Fujimi, Fujimi-cho, Nagano 399-0293, JAPAN Phone: +81-266-61-0614 FAX: +81-266-61-2051

> First issue June, 2018 in Japan Rev.20181219



Contact details

The Netherlands	Belgium	UK & Ireland
Elektrostraat 17 NL-7483 PG Haaksbergen	Zuiderlaan 14 bus 10 B-1731 Zellik	St. Mary's House, Church Lane Carlton Le Moorland Lincoln LN5 9HS
T: +31 (0)53 573 33 33 F: +31 (0)53 573 33 30 E: nl@texim-europe.com	T: +32 (0)2 462 01 00 F: +32 (0)2 462 01 25 E: belgium@texim-europe.com	T: +44 (0)1522 789 555 F: +44 (0)845 299 22 26 E: uk@texim-europe.com
Germany North	Germany South	Austria
Bahnhofstrasse 92 D-25451 Quickborn	Martin-Kollar-Strasse 9 D-81829 München	Warwitzstrasse 9 A-5020 Salzburg
T: +49 (0)4106 627 07-0 F: +49 (0)4106 627 07-20 E: germany@texim-europe.com	T: +49 (0)89 436 086-0 F: +49 (0)89 436 086-19 E: germany@texim-europe.com	T: +43 (0)662 216 026 F: +43 (0)662 216 026-66 E: austria@texim-europe.com
Nordic region	Italy	General information
Sdr. Jagtvej 12 DK-2970 Hørsholm	Via Matteotti 43 IT-20864 Agrate Brianza (MB)	info@texim-europe.com
T: +45 88 20 26 30 F: +45 88 20 26 39 E: nordic@texim-europe.com	T: +39 (0)39 971 3293 F: +39 (0)39 971 3293 E: italy@texim-europe.com	www.texim-europe.com

2019 version 1.0



