

<b>File Name</b>	<b>Specification For HINK 4.2" EPD</b>	<b>Module Number</b>	<b>HINK-E042A03</b>
<b>Version</b>	A/0	<b>Page Number</b>	1 of 33

# Specification for HINK 4.2"EPD

## Model NO.:HINK-E042A03

### Customer approval

<b>Customer</b>	
<b>Approval by</b>	
<b>Date of approval</b>	

<b>Prepared by</b>	<b>Checked by</b>	<b>Approval by</b>
Zhai chongzhi	Jia pengfei	Ma zewu





# THINGWELL ELECTRONICS

TEL:+86-755-27435731 FAX:+86-755-27132381

<http://www.lcdmaker.com>

<b>File Name</b>	<b>Specification For HINK 4.2'' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	2 of 33

<b>Version</b>	<b>Content</b>	<b>Date</b>	<b>Producer</b>
A/0	New release	2015/05/15	
A/1			



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	3 of 33

## CONTENTS

1	General Description .....	4
2	Features .....	4
3	Application .....	4
4	Mechanical Specification.....	5
5	Mechanical Drawing of EPD module.....	6
6	Input/Output Terminals .....	7
6.1	Pin out List .....	7
6.2	MCU Interface.....	9
6.2.1	MCU Interface selection.....	9
6.2.2	MCU Serial Peripheral Interface (3-wire SPI).....	10
7	Command Table.....	12
8	MAXIMUM RATINGS .....	17
9	Reference Circuit.....	18
10	Serial Peripheral Interface Timing.....	19
11	Optical characteristics.....	20
12	Reference Circuit.....	20
13	Typical Operating Sequence.....	23
13.1	Normal Operation Flow .....	23
13.2	Reference Program Code .....	24
14	Optical Characteristics.....	25
14.1	Specifications .....	25
14.2	Definition Of Contrast Ratio ... ..	26
14.3	Reflection Ratio... ..	27
14.4	Bi-stability... ..	27
15	Handling, Safety, and Environment Requirements .....	28
16	Reliability test.....	29
17	Block Diagram.....	30
18	Point and line standard .....	31
19	Packing .....	33

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	4 of 33

## 1 General Description

HINK-E042A03 is an Active Matrix Electrophoretic Display(AMEPD) , with interface and a reference system design. The 4. 2' active area contains 400×300 pixels, and has 1-bit full display capabilities. An integrated circuit contains gate buffer, source buffer, interface, timing control logic, oscillator, DC-DC. SRAM. LUT ,VCOM,and border are supplied with each panel.

## 2 Features

400×300 pixels display

White reflectance above 43%

Contrast ratio 10:1

Ultra wide viewing angle

Ultra low power consumption

Pure reflective mode

Bi-stable display Commercial temperature range

Landscape, portrait modes

Hard-coat antiglare display surface

Ultra Low current deep sleep mode

On chip display RAM

Waveform stored in On-chip OTP

Serial peripheral interface available

On-chip oscillator

On-chip booster and regulator control for generating VCOM, Gate and Source driving voltage

I2C signal master interface to read external temperature sensor

## 3 Application

Electronic Shelf Label System



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	5 of 33


#### 4 Mechanical Specifications

<b>Parameter</b>	<b>Specifications</b>	<b>Unit</b>	<b>Remark</b>
Screen Size	4.2	Inch	
Display Resolution	400(H)×300(V)	Pixel	
Active Area	84.8(H)×63.6.0(V)	mm	
Pixel Pitch	0.212×0.212	mm	
Pixel Configuration	Rectangle		
Outline Dimension	91.0(H)×77.0(V)×1.05(D)	mm	
Weight	TBD	g	


已确认此版本的所有图纸  
 签名: \_\_\_\_\_ 日期: \_\_\_\_\_

REV. :	DESCRIPTION	DATE
A0	初始版本	15.2.10
A1	更改FPC外形	15.5.16
A2	更改FPC外形	15.7.29


## FRONT VIEW




## SIDE VIEW



## BOTTOM VIEW



PIN	SIGNAL
1	CS2#
2	GPR
3	RESSE
4	VGL
5	VGH
6	TSCL
7	TSDA
8	RS1
9	BUSV
10	BRS#
11	D/C#
12	CS1#
13	DO
14	D1
15	VDDIO
16	VCI
17	VSS
18	VDD
19	NC
20	VSH
21	PREVGI
22	VSL
23	PREVGI
24	VCOM



- NOTES:
1. DISPLAY MODE 4.20" ARREY FOR EPD;
  2. DRIVE IC: SSD1608;SSD1618, SC5608 compatibility;
  3. RESOLUTION:400gate X 300source;
  4. pixel size:0.212mm X 0.212mm;
  5. Unspecified Tolerance:±0.20;
  6. Material conform to the ROHS standard

THINGWELL ELECTRONICS COMPANY LIMITED

ALL UNITS: mm	DATE	MODEL NUMBER :	SHEET: 1
DWN: X.Z.P	15.7.29	HINK-E042A01-A2	DATE: 15.7.29
CHK:		CUSTOMER NO.:	
APP:		P/N	
		PROJECTION	

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	7 of 33

## 6 Input/Output Terminals

### 6.1 Pin out List

Pin #	Type	Single	Description	Remark
1	O	CS1#	Slave Chip Select input pin	Note6-1
2	O	GDR	N-Channel MOSFET Gate Drive Control	
3	O	RESE	Current Sense Input for the Control Loop	
4	C	VGL	Negative Gate driving voltage	
5	C	VGH	Positive Gate driving voltage	
6	O	TSCL	I2C Interface to digital temperature sensor Clock pin	
7	I/O	TSDA	I2C Interface to digital temperature sensor Date pin	
8	I	BS1	Bus selection pin	Note 6-5
9	O	BUSY	Busy state output pin	Note 6-4
10	I	RES #	Reset	Note 6-3
11	I	D/C #	Data /Command control pin	Note 6-2
12	I	CS #	Chip Select input pin	Note 6-1
13	I/O	D0	serial clock pin (SPI)	
14	I/O	D1	serial data pin (SPI)	
15	I	VDDIO	Power for interface logic pins	
16	I	VCI	Power Supply pin for the chip	
17		VSS	Ground	
18	C	VDD	Core logic power pin	
19	C	VPP	Power Supply for OTP Programming	
20	C	VSH	Positive Source driving voltage	
21	C	PREVGH	Power Supply pin for VGH and VSH	
22	C	VSL	Negative Source driving voltage	
23	C	PREVGL	Power Supply pin for VCOM, VGL and VSL	
24	C	VCOM	VCOM driving voltage	

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	8 of 33

Note 6-1: This pin (CS#,CS1#) are the driver ic's chip select input connecting to the MCU. When CS# is pulled low, The master chip is enabled for MCU communication, and when CS1# is pulled low, the slaver chip is enabled, if CS# And CS1# pulled low at same time, the master and slaver chip are enabled to communication with mcu together.

Note 6-2: This pin (D/C#) is Data/Command control pin connecting to the MCU. When the pin is pulled HIGH, the data will be interpreted as data. When the pin is pulled LOW, the data will be interpreted as command.

Note 6-3: This pin (RES#) is reset signal input. The Reset is active low.

Note 6-4: This pin (BUSY) is Busy state output pin. When Busy is Low the operation of chip should not be interrupted and any commands should not be issued to the module. The driver IC will put Busy pin Low when the driver IC is working such as:

- Outputting display waveform; or
- Communicating with digital temperature sensor

Note 6-5: This pin (BS1) is for 3-line SPI or 4-line SPI selection. When it is "Low", 4-line SPI is selected.

When it is "High", 3-line SPI (9 bits SPI) is selected. Please refer to below Table.

**Table: Bus interface selection**

<b>BS1</b>	<b>MPU Interface</b>
L	4-lines serial peripheral interface (SPI)
H	3-lines serial peripheral interface (SPI) - 9 bits SPI



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	9 of 33

## 6.2 MCU Interface

### 6.2.1 MCU Serial Peripheral Interface (4-wire SPI)


The 4-wire SPI consists of SCLK (serial clock), SDIN (serial data), D/C# and CS#. D0 acts as SCLK and D1 acts as SDIN.

**Table -1 : Control pins of 4-wire Serial Peripheral interface**

Function	CS# pin	D/C# pin	SCLK pin
Write command	L	L	↑
Write data	L	H	↑

**Note:** ↑ stands for rising edge of signal

SDIN is shifted into an 8-bit shift register in the order of D7, D6, ... D0. The data byte in the shift register is written to the Graphic Display Data RAM (RAM) or command register in the same clock. Under serial mode, only write operations are allowed.



**Figure 6-1 : Write procedure in 4-wire Serial Peripheral Interface mode**

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	10 of 33

### 6.2.2 MCU Serial Peripheral Interface (3-wire SPI)

The 3-wire serial interface consists of SCLK (serial clock), SDIN (serial data) and CS#. In SPI mode, D0 acts as SCLK and D1 acts as SDIN. The operation is similar to 4-wire serial interface while D/C# pin is not used. There are altogether 9-bits will be shifted into the shift register in sequence: D/C# bit, D7 to D0 bit. The D/C# bit (first bit of the sequential data) will determine the following data byte in the shift register is written to the Display Data RAM (D/C# bit = 1) or the command register (D/C# bit = 0). Under serial mode, only write operations are allowed.

**Table -2 : Control pins of 3-wire Serial Peripheral interface**

Function	CS# pin	D/C# pin	SCLK pin
Write command	L	Tie LOW	↑
Write data	L	Tie LOW	↑

**Note:** ↑ stands for rising edge of signal




Figure 6-1 : Write procedure in 3-wire Serial Peripheral Interface mode

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	11 of 33

### 6.3 External Temperature Sensor Interface

There are two ways to let the module get the ambient temperature,

- 1) use the external temperature sensor interface, The module provides two I/O lines [TSDA and TSCL] for connecting digital temperature sensor for temperature reading sensing. TSDA will treat as SDA line and TSCL will treat as SCL line. They are required connecting with external pull-up resistor when they are used to connect to the temperature sensor, then the module will check the temperature automatically.
- 2) use any kinds of external temperature sensor to get the temperature value then converted to hex format, then use the spi interface send command 0x1A and the temperature value into the module. The temperature value how to converted to hex as the follow:
  1. When the Temperature value MSByte bit D11 = 0, the temperature is positive and value (DegC) = + (Temperature value)/16
  2. When the Temperature value MSByte bit D11 = 1, the temperature is negative and value (DegC) = ~ (2's complement of Temperature value)/16

12-bit binary (2's complement)	Hexadecimal Value	Decimal Value	Value [DegC]
0111 1111 0000	7F0	2032	127
0111 1110 1110	7EE	2030	126.875
0111 1110 0010	7E2	2018	126.125
0111 1101 0000	7D0	2000	125
0001 1001 0000	190	400	25
0000 0000 0010	002	2	0.125
0000 0000 0000	000	0	0
1111 1111 1110	FFE	-2	-0.125
1110 0111 0000	E70	-400	-25
1100 1001 0010	C92	-878	-54.875
1100 1001 0000	C90	-880	-55

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	12 of 33

## 7 Command Table

R/W#	D/C#	Hex	D7	D6	D5	D4	D3	D2	D1	D0	Command	Description					
0	0	01	0	0	0	0	0	0	0	1	Driver Output control	Gate setting					
0	1		A7	A6	A5	A4	A3	A2	A1	A0		Set A[8:0] = 127h					
0	1		0	0	0	0	0	0	0	A8		Set B[2:0] = 0h					
0	1		0	0	0	0	0	B2	B1	B0							
0	0	0C	0	0	0	0	1	1	0	0	Booster Soft start Control	Set A[7:0] = CFh					
0	1		1	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		Set B[7:0] = CEh					
0	1		1	B <sub>6</sub>	B <sub>5</sub>	B <sub>4</sub>	B <sub>3</sub>	B <sub>2</sub>	B <sub>1</sub>	B <sub>0</sub>		Set C[7:0] = 8Dh					
0	1		1	C <sub>6</sub>	C <sub>5</sub>	C <sub>4</sub>	C <sub>3</sub>	C <sub>2</sub>	C <sub>1</sub>	C <sub>0</sub>							
0	0	10	0	0	0	1	0	0	0	0	Deep Sleep mode	Deep Sleep mode Control					
0	1		0	0	0	0	0	0	0	A <sub>0</sub>							
												<table border="1"> <tr> <th>A[0] :</th> <th>Description</th> </tr> <tr> <td>0</td> <td>Normal Mode [POR]</td> </tr> <tr> <td>1</td> <td>Enter Deep Sleep Mode</td> </tr> </table>	A[0] :	Description	0	Normal Mode [POR]	1
A[0] :	Description																
0	Normal Mode [POR]																
1	Enter Deep Sleep Mode																
0	0	11	0	0	0	1	0	0	0	1	Data Entry mode setting	Define data entry sequence					
0	1		0	0	0	0	0	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		A [1:0] = ID[1:0] Address automatic increment / decrement setting The setting of incrementing or decrementing of the address counter can be made independently in each upper and lower bit of the address.  00 –Y decrement, X decrement, 01 –Y decrement, X increment, 10 –Y increment, X decrement, 11 –Y increment, X increment [POR]  A[2] = AM Set the direction in which the address counter is updated automatically after data are written to the RAM.  AM= 0, the address counter is updated in the X direction. [POR] AM= 1, the address counter is updated in the Y direction.					
0	0	12	0	0	0	1	0	0	1	0	SWRESET	It resets the commands and parameters to their S/W Reset default values except R10h-Deep Sleep Mode Note: RAM are unaffected by this command.					



# THINGWELL ELECTRONICS

TEL:+86-755-27435731 FAX:+86-755-27132381

<http://www.lcdmaker.com>

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	13 of 33

R/W#	D/C#	Hex	D7	D6	D5	D4	D3	D2	D1	D0	Command	Description
0	0	1A	0	0	0	1	1	0	1	0	Temperature Sensor Control (Write to temperature register)	Write to temperature register. A[7:0] – MSByte 01111111[POR] B[7:0] – LSByte 11110000[POR]
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		
0	1		B <sub>7</sub>	B <sub>6</sub>	B <sub>5</sub>	B <sub>4</sub>	0	0	0	0		
0	0	20	0	0	1	0	0	0	0	0	Master Activation	Activate Display Update Sequence  The Display Update Sequence Option is located at R22h  User should not interrupt this operation to avoid corruption of panel images.
0	0	21	0	0	1	0	0	0	0	1	Display Update Control 1	Option for Display Update Bypass Option used for Pattern Display, which is used for display the RAM content into the Display  OLD RAM Bypass option A [7] A[7] = 1: Enable bypass A[7] = 0: Disable bypass [POR]  A[4] value will be used as for bypass. A[4] = 0 [POR]  A[1:0] Initial Update Option - Source Control
0	1		A <sub>7</sub>	0	0	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		

A[1:0]	GSC	GSD
01 [POR]	GS0	GS1



# THINGWELL ELECTRONICS

TEL:+86-755-27435731 FAX:+86-755-27132381

http://www.lcdmaker.com

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	14 of 33

R/W#	D/C#	Hex	D7	D6	D5	D4	D3	D2	D1	D0	Command	Description		
0	0	22	0	0	1	0	0	0	1	0	Display Update Control 2	Display Update Sequence Option: Enable the stage for Master Activation		
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>			Parameter (in Hex)	
													Enable Clock Signal, Then Enable CP Then Load Temperature value Then Load LUT Then INITIAL DISPLAY Then PATTERN DISPLAY Then Disable CP Then Disable OSC	FF [POR]
													To Enable Clock Signal (CLKEN=1)	80
													To Enable Clock Signal, then Enable CP (CLKEN=1, CPEN=1)	C0
													To INITIAL DISPLAY + PATTEN DISPLAY	0C
													To INITIAL DISPLAY	08
													To DISPLAY PATTEN	04
													To Disable CP, then Disable Clock Signal (CLKEN=1, CPEN=1)	03
													To Disable Clock Signal (CLKEN=1)	01
												Remark: CLKEN=1: If CLS=VDDIO then Enable OSC If CLS=VSS then Enable External Clock CLKEN=0: If CLS=VDDIO then Disable OSC AND INTERNAL CLOCK Signal = VSS,		
0	0	24	0	0	1	0	0	1	0	0	Write RAM	After this command, data entries will be written into the RAM until another command is written. Address pointers will advance accordingly.		
0	0	2C	0	0	1	0	1	0	1	1	Write VCOM register	Write VCOM register from MCU interface		
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>				



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	15 of 33

R/W#	D/C#	Hex	D7	D6	D5	D4	D3	D2	D1	D0	Command	Description															
0	0	32	0	0	1	1	0	0	1	0	Write LUT register	Write LUT register from MCU [240 bits], (excluding the VSH/VSL and Dummy bit)															
0	1		LUT [30 bytes]																								
0	1																										
0	1																										
...	...																										
0	1																										
0	0	3A	0	0	1	1	1	0	1	0	Set dummy line period	Set A[7:0] = 1Ah															
0	1		0	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>																	
0	0	3B	0	0	1	1	1	0	1	1	Set Gate line width	Set B[3:0] = 8h															
0	1		0	0	0	0	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>																	
0	0	3C	0	0	1	1	1	1	0	0	Border Waveform Control	Select border waveform for VBD A [7] Follow Source at Initial Update Display A [7]=0: [POR] A [7]=1: Follow Source at Initial Update Display for VBD, A [6:0] setting are being overridden at Initial Display STAGE.  A [6] Select GS Transition/ Fix Level for VBD A [6]=0: Select GS Transition A[3:0] for VBD A [6]=1: Select FIX level Setting A[5:4] for VBD [POR] A [5:4] Fix Level Setting for VBD															
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	0	0	A <sub>1</sub>	A <sub>0</sub>			<table border="1" style="margin-left: 20px;"> <tr> <td>A[5:4]</td> <td>VBD level</td> </tr> <tr> <td>00</td> <td>VSS</td> </tr> <tr> <td>01</td> <td>VSH</td> </tr> <tr> <td>10</td> <td>VSL</td> </tr> <tr> <td>11[POR]</td> <td>HiZ</td> </tr> </table> A [1:0] GS transition setting for VBD (Select waveform like data A[3:2] to data A[1:0]) <table border="1" style="margin-left: 20px;"> <tr> <td>A[1:0]</td> <td>GSA</td> <td>GSB</td> </tr> <tr> <td>01 [POR]</td> <td>GS0</td> <td>GS1</td> </tr> </table>	A[5:4]	VBD level	00	VSS	01	VSH	10	VSL	11[POR]	HiZ	A[1:0]	GSA	GSB	01 [POR]
A[5:4]	VBD level																										
00	VSS																										
01	VSH																										
10	VSL																										
11[POR]	HiZ																										
A[1:0]	GSA	GSB																									
01 [POR]	GS0	GS1																									



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	16 of 33

R/W#	D/C#	Hex	D7	D6	D5	D4	D3	D2	D1	D0	Command	Description
0	0	44	0	1	0	0	0	1	0	0	Set RAM X - address Start / End position	Specify the start/end positions of the window address in the X direction by an address unit  A[4:0]: XSA[4:0], XStart, POR = 00h B[4:0]: XEA[4:0], XEnd, POR = 1Dh
0	1		0	0	0	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		
0	1		0	0	0	B <sub>4</sub>	B <sub>3</sub>	B <sub>2</sub>	B <sub>1</sub>	B <sub>0</sub>		
0	0	45	0	1	0	0	0	1	0	1	Set Ram Y- address Start / End position	Specify the start/end positions of the window address in the Y direction by an address unit  A[8:0]: YSA[8:0], YStart, POR = 000h B[8:0]: YEA[8:0], YEnd, POR = 13Fh
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		
0	1		0	0	0	0	0	0	0	A <sub>8</sub>		
0	1		B <sub>7</sub>	B <sub>6</sub>	B <sub>5</sub>	B <sub>4</sub>	B <sub>3</sub>	B <sub>2</sub>	B <sub>1</sub>	B <sub>0</sub>		
0	1		0	0	0	0	0	0	0	B <sub>8</sub>		
0	0	4E	0	1	0	0	1	1	1	0	Set RAM X address counter	Make initial settings for the RAM X address in the address counter (AC) A[4:0]: XAD[4:0], POR is 00h
0	1		0	0	0	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		
0	0	4F	0	1	0	0	1	1	1	1	Set RAM Y address counter	Make initial settings for the RAM Y address in the address counter (AC) A[8:0]: YAD8:0], POR is 000h
0	1		A <sub>7</sub>	A <sub>6</sub>	A <sub>5</sub>	A <sub>4</sub>	A <sub>3</sub>	A <sub>2</sub>	A <sub>1</sub>	A <sub>0</sub>		
0	1		0	0	0	0	0	0	0	A <sub>8</sub>		
0	1	FF	1	1	1	1	1	1	1	1	NOP	This command is an empty command; it does not have any effect on the display module. However it can be used to terminate Frame Memory Write or Read Commands.



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	17 of 33

## 8 MAXIMUM RATINGS

**Table 8-1: Maximum Ratings**

<b>Symbol</b>	<b>Parameter</b>	<b>Rating</b>	<b>Unit</b>
V <sub>CI</sub>	Logic supply voltage	-0.5 to +3.7	V
V <sub>IN</sub>	Logic Input voltage	-0.5 to V <sub>DDIO</sub> +0.5	V
V <sub>OUT</sub>	Logic Output voltage	-0.5 to V <sub>DDIO</sub> +0.5	V
T <sub>OPR</sub>	Operation temperature range	0 to 50	°C
T <sub>STG</sub>	Storage temperature range	-25 to 85	°C

Maximum ratings are those values beyond which damages to the device may occur. Functional operation should be restricted to the limits in the Electrical Characteristics tables or Pin Description section

This device contains circuitry to protect the inputs against damage due to high static voltages or electric fields; however, it is advised that normal precautions be taken to avoid application of any voltage higher than maximum rated voltages to this high impedance circuit. This device may be light sensitive. Caution should be taken to avoid exposure of this device to any light source during normal operation. This device is not radiation protected.

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	18 of 33

## 9 ELECTRICAL CHARACTERISTICS

The following specifications apply for: VSS=0V, VCI=3.0V, T<sub>OPR</sub>=25°C.

**Table 9-1: DC Characteristics**


Symbol	Parameter	Test Condition	Applicable pin	Min.	Typ.	Max.	Unit
V <sub>CI</sub>	VCI operation voltage		VCI	2.4	3.0	3.7	V
V <sub>IH</sub>	High level input voltage		D1 (SDIN), D0 (SCLK), CS#, D/C#, RES#, BS1, TSDA, TSCL	0.8V <sub>DDIO</sub>			V
V <sub>IL</sub>	Low level input voltage					0.2V <sub>DDIO</sub>	V
V <sub>OH</sub>	High level output voltage	IOH = -100uA	BUSY, TSDA,	0.9V <sub>DDIO</sub>			V
V <sub>OL</sub>	Low level output voltage	IOL = 100uA	TSCL			0.1V <sub>DDIO</sub>	V
I <sub>update</sub>	Image update current			-	8.5	12	mA
I <sub>standby</sub>	Standby panel current			-	-	5	uA

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	19 of 33

## 10 Serial Peripheral Interface Timing

The following specifications apply for: VSS=0V, VCI=2.4V to 3.7V, T<sub>OPR</sub>=25°C

Symbol	Parameter	Min	Typ	Max	Unit
t <sub>cycle</sub>	Clock Cycle Time	250	-	-	ns
t <sub>AS</sub>	Address Setup Time	150	-	-	ns
t <sub>AH</sub>	Address Hold Time	150	-	-	ns
t <sub>CSS</sub>	Chip Select Setup Time	120	-	-	ns
t <sub>CSH</sub>	Chip Select Hold Time	60	-	-	ns
t <sub>DSW</sub>	Write Data Setup Time	50	-	-	ns
t <sub>DHW</sub>	Write Data Hold Time	15	-	-	ns
t <sub>CLKL</sub>	Clock Low Time	100	-	-	ns
t <sub>CLKH</sub>	Clock High Time	100	-	-	ns
t <sub>R</sub>	Rise Time [20% ~ 80%]	-	-	15	ns
t <sub>F</sub>	Fall Time [20% ~ 80%]	-	-	15	ns



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	20 of 33

## 11 Power Consumption

Parameter	Symbol	Conditions	TYP	Max	Unit	Remark
Panel power consumption during update	-	-	26.4	40	mW	-
Power consumption in standby mode	-	-	-	0.035	mW	-

## 12 Reference Circuit






Figure . 12-1

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	21 of 33



**Figure . 12-2**



**Figure . 12-3**

File Name	Specification For HINK4. 2' EPD	Module Number	HINK-E042A01
Version	A/0	Page Number	22 of 33





Figure . 12-4

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	23 of 33


## 13 Typical Operating Sequence

### 13.1 Normal Operation Flow



File Name	Specification For HINK4. 2' EPD	Module Number	HINK-E042A01
Version	A/0	Page Number	24 of 33

## 13.2 Reference Program Code



**Note1:** The Vcom for Different batches EPD is different.Holitech will provide different vcom value for different batches of EPD.

**Note2:** The waveform for Different batches EPD is different.Holitech will provide different waveform for different batches of EPD.



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	25 of 33

## 14 Optical characteristics

### 14.1 Specifications

Measurements are made with that the illumination is under an angle of 45 degrees, the detection is perpendicular unless otherwise specified.

T=25°C

SYMBOL	PARAMETER	CONDITIONS	MIN	TYPE	MAX	UNIT	Note
R	Reflectance	White	34	43	-	%	Note 9-1
Gn	2Grey Level	-	-	$DS+(WS-DS) \times n(m-1)$	-	L*	-
CR	Contrast Ratio	indoor	-	10	-	-	-
T <sub>update</sub>	Update time	25°C	-	680ms	-	sec	-
Panel's life		0°C~50°C		1000000 times or 5 years			Note 9-2

WS : White state, DS : Dark state

Gray state from Dark to White : DS、WS

m : 2

Note 9-1 : Luminance meter : Eye – One Pro Spectrophotometer

Note 9-2 : When work in temperature below 0 degree or above 50 degree , we do not recommend because the panel's life will not be guaranteed


<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	26 of 33

## 14.2 Definition of contrast ratio

The contrast ratio (CR) is the ratio between the reflectance in a full white area (R1) and the reflectance in a dark area (Rd) :

R1: white reflectance      Rd: dark reflectance

$$CR = R1/Rd$$




<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	27 of 33

### 14.3 Reflection Ratio

The reflection ratio is expressed as :

$$R = \text{Reflectance Factor white board} \times (L_{\text{center}} / L_{\text{white board}})$$

L center is the luminance measured at center in a white area (R=G =B=1) . L white board is the luminance of a standard white board . Both are measured with equivalent illumination source . The viewing angle shall be no more than 2 degrees .



### 14.4 Bi-stability

1. The value of Contrast ratio in different time as follows:

Bi-stability	Result
250 hours	CR >8
500 hours	CR >8
750 hours	CR >7.5
1000 hours	CR >7



<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	28 of 33

## 15 HANDLING, SAFETY AND ENVIROMENTAL REQUIREMENTS

### WARNING

The display glass may break when it is dropped or bumped on a hard surface . Handle with care.  
Should the display break, do not touch the electrophoretic material . In case of contact with electrophoretic material , wash with water and soap.

### CAUTION

The display module should not be exposed to harmful gases , such as acid and alkali gases , which corrode electronic components.

Disassembling the display module can cause permanent damage and invalidate the warranty agreements.

Observe general precautions that are common to handling delicate electronic components . The glass can break and front surfaces can easily be damaged . Moreover the display is sensitive to static electricity and other rough environmental conditions.

### Data sheet status

Product specification	The data sheet contains final product specifications.
-----------------------	---

### Limiting values

Limiting values given are in accordance with the Absolute Maximum Rating System (IEC 134).  
Stress above one or more of the limiting values may cause permanent damage to the device.  
These are stress ratings only and operation of the device at these or any other conditions above those given in the Characteristics sections of the specification is not implied . Exposure to limiting values for extended periods may affect device reliability.

### Application information

Where application information is given , it is advisory and dose not form part of the specification.

### Product Environmental certification

ROHS
------

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	29 of 33

## 16 Reliability test


	<b>TEST</b>	<b>CONDITION</b>	<b>METHOD</b>	<b>REMARK</b>
1	High-Temperature Operation	T = 50°C,30% for 240 hrs	IEC 60 068-2-2Bp	
2	Low-Temperature Operation	T = 0°C for 240 hrs	IEC 60 068-2-2Ab	
3	High-Temperature Storage	T = +70°C, 23% for 240 hrs Test in white pattern	IEC 60 068-2-2Bp	
4	Low-Temperature Storage	T = -25°C for 240 hrs Test in white pattern	IEC 60 068-2-2Ab	
5	High Temperature, High-Humidity Operation	T=+40°C, RH=90%for168hrs	IEC 60 068-2-3CA	
6	High Temperature, High-Humidity Storage	T=+60°C, RH=80%for240hrs Test in white pattern	IEC 60 068-2-3CA	
7	Temperature Cycle	[-25°C 30mins]→ [+70°C 30mins] ,70cycles Test in white pattern	IEC 60 068-2-14NB	
8	UV exposure Resistance	765 W/m <sup>2</sup> for 168 hrs,40°C	IEC 60 068-2-5 Sa	
9	Electrostatic discharge	Air-mode:+/-8kV, Contact-mode:+/-6kV, 330Ω,150pF	IEC61000-4-2	
10	Package Vibration	1.04G,Frequency : 10~500Hz Direction : X,Y,Z Duration:1 hours in each direction	Full packed for shipment	
11	Package Drop Impact	Drop from height of 122 cm on Concrete surface Drop sequence:1 corner, 3edges, 6face One drop for each.	Full packed for shipment	
12	Altitude test Operation	700hPa ( =3000 m ),48Hr		
13	Altitude test Storage	260hPa ( =10000 m ),48Hr Test in white pattern		
14	Stylus Tapping	POLYACETAL Pen: Top R:0.8mm Load: 300gf Speed: 30times/min Total 13,500times,	Test should be done with a bezel	Pass criteria – no glass breakage or damage to microcapsules

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	30 of 33

Actual EMC level to be measured on customer application.

Note : The protective film must be removed before temperature test.

## 17 Block Diagram




<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	31 of 33

## 18 Point and line standard

### Shipment Inseption Standard


Environment	Temperature	Humidity	Illuminance	Distance	Time	Angle	
	20°C ~ 25°C	40% ~ 55%RH	800 ~ 1200Lux	200 ~ 300mm	35Sec		
appearance standard	Defet type	Inspection	Standard		Part-A		
	dead/ switch point (point overproof)	Electric Display	D ≤ 0.2mm		Ignore		
			0.2mm < D ≤ 0.25mm		N ≤ 2		
			D > 0.25mm		Not Allow		
	2. Line  (No switch)	L ≤ 0.24; W ≤ 0.06	—	Ignore		No defect within 20mm range of PartA	
		0.24 ≤ L ≤ 0.4; 0.06 < W ≤ 0.1	—	N ≤ 2			
		L > 0.4; W > 0.1	—	0		Part-A	
	3.line (Switching line)	Electric Display	Ignore in gray scale viewing In Blak&white viewing Follow Non-Switching Criteria				
	4.Display unwork	Electric Display	Not Allow				
	5.Display error	Electric Display	Not Allow				
	6.PS PET warping	Vsual	cannot beyond 1/2 of the border				
	7.Protector hurt	Vsual	L ≤ 2mm, W ≤ 0.05mm, Ignore;				
			L > 2mm, W > 0.05mm, Not Allow;				
8.Adhesive coating	Vsual	Bubble: 0.1mm ≤ D < 0.3mm & N ≤ 2					
9.Packing	Vsual	cannot be dirty and breakdown; must be marked and identified					
Remark	1. Cannot be defect & failure cause by appearance defect;						
	2. Cannot be larger size cause by appearance defect;						

<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	32 of 33



$$L = L1 + L2$$

Line Defect



$$D = (L + W) / 2$$

Spot Defect

L=long W=wide D=point size

Edition	Content	Date
1	New edition	Sep.26.2014





<b>File Name</b>	<b>Specification For HINK4. 2' EPD</b>	<b>Module Number</b>	<b>HINK-E042A01</b>
<b>Version</b>	A/0	<b>Page Number</b>	33 of 33

**19 Packing**

**TBD**

## The Netherlands



Elektrostraat 17  
NL-7483 PG Haaksbergen

T: +31 (0)53 573 33 33  
F: +31 (0)53 573 33 30  
E: [nl@texim-europe.com](mailto:nl@texim-europe.com)

## Belgium



Zuiderlaan 14 bus 10  
B-1731 Zellik

T: +32 (0)2 462 01 00  
F: +32 (0)2 462 01 25  
E: [belgium@texim-europe.com](mailto:belgium@texim-europe.com)

## UK & Ireland



St. Mary's House, Church Lane  
Carlton Le Moorland  
Lincoln LN5 9HS

T: +44 (0)1522 789 555  
F: +44 (0)845 299 22 26  
E: [uk@texim-europe.com](mailto:uk@texim-europe.com)

## Germany North



Bahnhofstrasse 92  
D-25451 Quickborn

T: +49 (0)4106 627 07-0  
F: +49 (0)4106 627 07-20  
E: [germany@texim-europe.com](mailto:germany@texim-europe.com)

## Germany South



Martin-Kollar-Strasse 9  
D-81829 München

T: +49 (0)89 436 086-0  
F: +49 (0)89 436 086-19  
E: [germany@texim-europe.com](mailto:germany@texim-europe.com)

## Austria



Warwitzstrasse 9  
A-5020 Salzburg

T: +43 (0)662 216 026  
F: +43 (0)662 216 026-66  
E: [austria@texim-europe.com](mailto:austria@texim-europe.com)

## Nordic region



Sdr. Jagtvej 12  
DK-2970 Hørsholm

T: +45 88 20 26 30  
F: +45 88 20 26 39  
E: [nordic@texim-europe.com](mailto:nordic@texim-europe.com)

## General information



[info@texim-europe.com](mailto:info@texim-europe.com)  
[www.texim-europe.com](http://www.texim-europe.com)